

Data sheet Powador-protect



## Measuring. Controlling. Protecting. Grid management with Powador-protect.

Powador-protect is a voltage and frequency protection device and a control medium- or low-voltage grid. If an intertect can be used as central interface protection according to VDE-AR-N 4105 and CEI 0-21. Powador-protect also offers As a voltage and frequency protection the functionality for feed-in manage- device, Powador-protect provides a sinment. It evaluates potential free contacts gle-fault tolerance (redundant design). provided by the control system of the distribution network operator and transmits configurable feed-in commands as defined by the distribution network operators.

As a protection device, Powadorprotect constantly measures the voltage and frequency grid parameters. If a limit violation of grid parameters is detected, Powador-protect triggers the interface switch and disconnects the PV System from the grid. This function is available with inverters from any manufacturer. The best results are achieved when

Powador-protect is operated with KACO new energy three-phase inverters or unit for PV systems that feed into the transformerless single-phase inverters: KACO new energy inverters are equipped face protection test is not possible due to ex works with internal interface a large number of string inverters or lack switches that are controlled directly by of inverter test terminals, Powador-pro- Powador-protect.\* No external interface switches are necesssary.

> This means that if a single error occurs in the device, the safety functions always remain intact: the fault is detected and signaled for maintenance.

For smaller systems, Powador-protect is the ideal solution because some distribution network operators require voltage drops between the inverter and meter to be taken into account. If there are long distances, shutdowns may occur in grids with high voltages because of the voltage drop between inverter and meter. Powador-protect is installed in the main distribution system and measures the

voltage directly at the meter. The internal protection setting on the inverter can therefore be set higher.

Powador-protect also offers another important feature: feed-in management. In some countries, law requires managed, remote-controlled power reduction of PV systems above a certain installed power. Formerly, a separate device was required for this purpose to send the corresponding signals of a ripple control receiver to the inverter as a control command. Powador-protect combines the functions of grid and system protection and feed-in management, saving space and money.

During feed-in management, Powadorprotect can manage the signals of the ripple control receiver for up to 31 inverters

\* Please note the Application note "Powador protect" for compability.

## **Technical data**

Powador-protect

Electrical data	Powador-protect		
Supply			
Power supply	100–264 V AC		
Rated voltage	230 V AC		
Max. power consumption	2.5 W		
Measurement			
r.m.s. value of grid voltage	0 – 300 V AC		
Frequency	40-70 Hz		
Rated frequency	50 Hz		
Actuation of external tie	circuit-breaker		
Max. AC current	2.0 A		
Max. AC voltage:	250 V		
Max. AC current	8.0 A		
Max. DC voltage:	30 V		
Mechanical data			
Interfaces			
Measurement	Screw terminals, 4-pole (L1/L2/L3/N)		
Switch contacts	2 changeover contacts for connecting externa		
Ripple control receiver	Screw terminals		
Inverter	Screw terminals for inverter off Screw terminals and RJ45 port for RS485		
General mechanical data			
Display	LCD 2 x 16 characters, 3 LEDs (operating stat		
Controls	2 control buttons, 1 release test		
Mounting	Top-hat rails or wall mounts		
Ambient temperature	-20 °C +70 °C		
Protection class	IP20		
Housing	Polycarbonate		
H x W x D	89.5 x 107 x 63 mm		
Weight	310 g		

tie circuit-breakers
s)

00000 ವಿನ⊏≲≦		0000 00000 00000 00000
-10	111	
• •	POWADOR-protect	10
• 🕇		10
• •	KACO 📎	TEST
10		
CAN H CAN H CAN H	RS4850 RS4850 RS4850 RS4850 RS4850 RS4850	
00000		J1J2J3J4

## Powador-protect

Grid and system protection as per VDE-AR-N 4105 and CEI 0-21

Individual voltage and frequency adjustment options via the "User Defined" menu selection

Triggers the inverter's integrated coupler circuit-breaker

Also as a supplement to Powador-proLOG

Temporary protection according to the German Medium Voltage Directives